

ETHAN ALLEN[®]

Pharmacy Floor Lamp Assembly Instructions 09-2574 / 09-2575

IMPORTANT SAFETY INSTRUCTIONS

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, AND PERSONAL INJURY:

This lighting fixture is for indoor use only. This lamp is equipped with a polarized plug. One plug blade is wider than the other. DO NOT MODIFY the plug or power cord in any way. DO NOT EXCEED the recommended bulb wattage. Use only the type of bulb specified. Keep flammable materials away from the bulb. DO NOT OPEN the product or alter the wiring in any manner. Extension cord: follow precautions provided with the power cord.

Use care when unpacking. Locate ALL THE PARTS INCLUDED before disposing of packaging materials. Remove the silica gel packet from the socket before plugging the lamp into an outlet.

ASSEMBLY, CARE, AND TROUBLESHOOTING

- No tools required for assembly
- Light bulb is not included

Parts Included: (Refer to the Figure)

- A. Shade
- B. Socket House
- C. Adjustment Key
- D. Lamp Pole
- E. Fixture Base
- F. Plastic Cover
- G. Electrical Plug

Assembly Procedure: (Refer to the Figure)


1. Remove all parts carefully from the carton.
2. Thread the bottom nipple of lamp pole (D) into the opening of fixture base (E).
3. Attach shade (A) onto socket house (B).
4. Insert light bulb Type T, maximum 40 watt into the socket.
5. Remove plastic cover (F) from electrical plug (G).
6. Plug lamp into electrical outlet.

Adjustment Instructions (Refer to the Figure)

1. Loosen adjustment key (C).
2. Adjust lamp by pulling or pushing upper pole up or down to desired height. Or swing socket house (B) to get desired position.
3. Tighten the adjustment key (C).

Caring for and cleaning your lamp:

1. To clean, wipe with a soft dry cloth
2. DO NOT USE cleaners, scouring pads, etc.
3. Unplug lamp and allow bulb to cool before changing bulb.



SAVE THESE INSTRUCTIONS

ETHAN ALLEN[®]

Troubleshooting:

Problem:	Possible cause:	Correction:
Bulb does not light	Bulb is burnt or damaged	Replace bulb
	Power to lamp is off	Confirm power is on
	Lamp is not plugged in	Confirm lamp is plugged in

If the fixture still does not work after troubleshooting, please contact your local Ethan Allen Design Center.

SAVE THESE INSTRUCTIONS